


WELCOME TO THE TIVO® EXPERIENCE!


The TiVo experience instantly gives you total control of the TV programming you love, and much more! The TiVo streaming device also connects to the Internet and gives you access to On Demand as well as movies and TV shows from a variety of streaming apps.



Press the TiVo button on your TiVo remote control to get to the Home screen, the starting point for all of TiVo's amazing features.

SEEK AND YOU SHALL FIND!

Only the TiVo experience offers fully integrated search. No other device instantly scans across live TV, recorded shows, On Demand and streaming apps like Netflix to find exactly what you want. With your voice remote in hand, you have an entertainment search engine that lets you start watching what you want in just seconds!




Search by show title, episode title, show description, or person name (actor, director, etc.). The TiVo service searches across all content at the same time. Simply press and release the Google Assistant button and speak naturally into the remote to get started.

THE SMARTBAR

READY WHEN YOU ARE

The SmartBar, located at the bottom of the Home screen, predicts shows to watch based on what your household usually watches at a particular time or day. For example, if you normally watch the previous night's late-night talk show the next morning, you'll see it in the SmartBar when you wake up. If the kids tend to watch shows while dinner's cooking, those shows will be waiting in the SmartBar at that time each day.



REMOTE HOW-TO'S

PAIRING

To control your TiVo box with your voice, you must use a TiVo voice remote that is paired correctly with your TiVo box. Usually, the remote is paired when you insert the batteries, but if you are having trouble using voice commands, you may have to re-pair it.

1. Press and hold the TiVo button and BACK button simultaneously until the activity light at the top of the remote illuminates red, then release the buttons.
2. Release the buttons. The activity light will flash slowly, then flash quickly five times.

VOICE COMMANDS

To issue a voice command, press and release the Google Assistant button and speak naturally into the remote. You'll see results from Google, with additional results from the TiVo service.

Here are some things you can do voice:

- Tune directly to a channel you want to watch with the sound of your voice: "Tune to Hallmark Channel" "Tune to ESPN"
- Search or browse: "Find Modern Family" or "Show me some action movies."


Hint: Add on to your initial command to get more specific. For example, after the command, "Show me some action movies," you could add "Just the ones with Bruce Willis."

- Launch an app: "Launch Netflix."
- Go to a TiVo menu screen: "Take me home" or "Show me the Guide."
- Get information from the Internet:
 - "What's my weather forecast?"
 - "What's the capital of Texas?"

TIPS & TRICKS

- Press the TiVo button once to go to the Home screen, or twice to **go to the My Shows list** - your list of available shows.
- Channel Up/Down does more than change the channel- it also pages up or down through lists of shows or menu items.

Welcome to the TIVO EXPERIENCE



astound.com/support

© 2021 TiVo Inc. All rights reserved. Patented. U.S. pat. nos. at www.tivo.com/patents. TiVo, the TiVo logo, OnePass, WishList, the Instant Replay logo, the Jump logo, the Thumbs Up logo and the Thumbs Down logo are registered trademarks of TiVo Inc. or its subsidiaries worldwide. Available where technology permits. Photos are for illustrative purposes only. iOS is a registered trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. All other trademarks are the property of their respective owners.


For safety and compliance information, visit tivo.com/safety-compliance.

Astound
Broadband
Powered by **RCN**



THE CONTENT YOU WANT, THE WAY YOU WANT IT.

CUSTOMIZE YOUR HOME SCREEN


You can choose how to display a video on the Home screen, or choose to turn it off completely. Just select the menu icon , then select User Preferences > Video Window & Background. To turn video off on all screens, set Display Video Window to No.

When Display Video Window is set to Yes, Home screen options include:


Full screen (background): The currently-playing video is shown as a full-screen video in the background of the Home screen

Top right: The currently-playing video is shown in the upper-right corner of the Home screen.


Off: The currently-playing video is not displayed on the Home screen.



FULL SCREEN



TOP RIGHT




OFF

BOOKMARKS

FIND NOW, WATCH NOW... OR LATER.

When you look for shows and movies using the TiVo menus, your options will include videos available to stream from On Demand and other video providers - no need to switch to a different catalog or app!

Don't have time to watch it now? Rather than search for it again later, bookmark it, and it'll be waiting in My Shows when you're ready.




BRING ALL YOUR ENTERTAINMENT TOGETHER.

Get all your shows, movies, and more from one simple and easy-to-navigate menu. Just click the Home button on your remote and a world of entertainment is at your fingertips.

TAKE A SHORTCUT TO GREAT SHOWS.

So many shows, so little time! TiVo's What to Watch lets you browse shows available to stream, bookmark, or watch live.


With the On TV Today, Sports, Movies categories and more, you'll find exactly what you're looking for. Plus, with the Trending strip, never miss out on the newest, hottest shows that everyone else is watching.




APPS & GAMES


EVERYTHING, WITH ONE REMOTE


You can access all the apps, games, and music available from the Google Play store, all with your TiVo remote control. Just select Apps & Games from the Home screen, select one of the Google Play tiles (Google Play Games, Google Play Music, etc.) and sign in to the Google Play store with your Gmail username and password.




You can also get access by clicking the grid button  on your remote to instantly jump to the Apps & Games screen.


ON DEMAND

Whether you want to watch the latest movies, old favorites, or the hottest shows, Astound On Demand has it available for you. Simply press the VOD button  on your remote to go directly to the On Demand library. You can also get to the On Demand menu directly from the Home Screen.

To exit out of the program you're watching and return to Live TV, hit the Exit button  on your remote.



RECORD YOUR SHOWS


There are two ways to record a program: a single recording or a OnePass series recording. To record a show you're watching, simply hit the 'i' button  on your remote and follow the prompts to record the program. You can also set a future recording by clicking on the program name in the guide and choose 'Record just this episode.' To create a OnePass series recording, simply find a show you want to watch, highlight it, then choose "Create a OnePass". Now you can watch a series from beginning to end, or start on any episode or season you want. OnePass gathers every episode of a series, and adds them all right to your My Shows list. If it's not available from On Demand, OnePass fills in the gaps with episodes from providers like Netflix.






MY SHOWS

FIND. WATCH. REPEAT.

All of your On Demand and other streaming videos appear in the My Shows list. To get to the My Shows list from any menu screen or from live TV, just press the Home button  once, highlight My Shows, and click OK. At the top of the My Shows list, you'll see All Shows that will have everything you have recorded or bookmarked. Below that, filters like Movies, TV Series, and Kids help you narrow your My Shows choices instantly so you can quickly find what you're looking for to watch. To exit out of your program and return to Live TV, simply hit the Exit button .



STARTOVER/CATCH-UP

With Startover and Catch-up you never have to worry about missing a show again. The power is in the green arrow . When you see the green arrow, , it means you can start that program over from the very beginning. You can even go backwards in time on the guide to start a show over you may have missed by simply hitting the left arrow key, the Ok button, and then select Watch now from Restart/Catch Up. You can return to live TV by hitting the Exit button  on your remote control

